

Bantam Base Attachment Pro Tips

1. Take one of the two U-shaped foam pieces from the kiosk shipping container .



2. Place the U-shaped foam piece under the kiosk near the bottom. Bolt holes are on the bottom.

3. Install the bolts about halfway, starting at the top in a



**diagonal pattern.
Tighten bolts when you've put all ten in.**